



## DMX CHART – LUXIBEL B PANEL180TW

### 2-Channel Mode

Channel	Value	Function
CH 1	0-255	Dimmer
CH 2	0-255	CCT

### 3-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer
CH 3	0-255	CCT

### 6-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer
CH 3	0-255	CCT
CH 4	0-255	Strobe
CH 5	0-255	Frequency preset
CH 6	0-255	4 types of dimming curve